Portable Food Warmer

User's Manual

Welcome you being the customer of our factory, thank you on behalf of the whole staff!
Our factory mainly produces the catering equipment. It concludes the grills series, fryers series, broilers series, food displays series and the snacks machine series.
Please read the manual seriously before using.

WARNING:

1. Safety grounding before using!
2. No spraying water when cleaning!

HW series products are designed with attractive appearance, reasonable structure, convenient operation and safe using. Its advantage is heating quickly and saving energy. It is applicable for hotels, shopping malls, supermarkets and other passenger flowing sites.

I. Basic Parameter

Model	Voltage(V)	Switch	Power(W)	Dimension
HCW-620	220	1 Set	1000	630*350*560mm

II. Transportation and Storage

This product should be treated carefully in transportation. The product with packages couldn't be put in open air sites for a long time. It should be put in good-Ventilated warehouse without causticity air. It can't be put upside down. And please take rain resistances when it is in open air temporarily.

III. Safety Precautions and Working Surroundings:

A. The product should be located at a steady area and departed from noncombustible items (i.e. the wall) for more than 10 cm(left and right side), more than 20 cm (back hand side).
B. The working voltage must match what is shown in the product.
C. The switch, fuse, and leakage protector should be installed close to the product. No sundries can be in front of the product.
D. It must be safe grounding before using.
E. Please inspect if the components are connected securely and safety grounding well done before starting up.
F. Please choose the same model wires when replacing them and ask specialized persons to replace them.
G. The installation and repair of the product must be processed by the professionals who have an Electrician operation certificate.

IV. Operational Approach:

A. Thermostat is in the front. It controls the working temperature of the element.
B. Switch the power before toasting. Then turn the thermostat clockwise to the temperature number needed. Thus the orange pilot lamp will be light and the elements begin working. When the temperature rises to the target, the thermostat will cut off the power and the pilot lamp black out with elements that stop working. After the temperature comes down, the thermostat will connect the power and the red pilot lamp light. The elements start working and the temperature goes up. Such iterations keep the temperature constant. One can adjust the temperature to match different foods.
C. Please clean up the oil in the oil box timely.
D. If there is any abnormal occurrence, please stop the machine immediately. It will be used after inspection and trouble remedy.
   During transportation, the machine should not be shaken, or upside down, pressed and kicked.

V. Clean Up and Maintenance

A. Please keep power off when cleaning up.
B. Please clean the surface of the machine and the wire using a cleanser without corrosive objects. DO NOT USE WATER TO WASH THE APPLIANCE PART.
C. Please clean the water in the oil box timely when cleaning up the machine.

VI. Warranty Terms

A. Six months three guarantees.
B. Three guarantees period:
   The three guarantees period is from the bill date the machine is sold out. The repairing date is not included. If the last day of the guarantee period is a holiday, then the day after the holiday will be the last day.
C. The following cases do not belong to the three guarantees, machines can be repaired with charges:Exceed the three guarantees period:
   a. There is no three guarantees proof or receipt:
      b. The machine does not conform to the three guaranteed proofs or the proof is altered.
      c. The machine is damaged because it is used or maintained not according to the manual. The machine is damaged by irresistible force. All the replaced spares and parts belong to the producer of the machine.The producer will not bear other liability for restitution except warranty.

(When the manual is changed, there will not be a notice)